

### CIRCUIT BREAKERS

CIRCUIT BREAKER	Location	Ampere Rating
Lighting System	Integral with Headlight Switch	
	Coronet .....	20
	Dart .....	15
Power Seats, Top Lift*	Behind left front kick panel .....	30
Power Windows	Behind left front kick panel .....	30
Windshield Wiper	Integral with Wiper Switch .....	
	Single Speed .....	5
	Variable Speed .....	6

\* Electric Window Lifts, and Power Seats — Coronet only.

### LIGHT BULBS

	Dart	Coronet		Dart	Coronet
Back-up Lights .....	1073	1073	Oil Pressure Indicator .....	158	158
Clock .....	57	*	Panel and/or Ridge Light .....	90	90
Dome Lights .....	1004	1004	Park and Turn Signal .....		
Door and/or Pocket .....	90	90	Radio .....	1893	1893
Emergency Flasher .....	57	57	Sealed Beam - Hi-Beam (No. 1) .....		4001
Gear Selector Indicator .....	1445	1445	Sealed Beam - Hi-Lo Beam (No. 2) .....		4002
Gear Selector with Console .....	57	57	Sealed Sealed Beam - Single "7" ....	6012	
Glove Compartment .....	1891	1891	Tachometer .....		57
Handbrake Indicator .....	57	57	Tail Stop and Turn Signal .....	1034	1034
Heater and/or A.C. Control .....	**	**	Trunk and/or Under Hood Light .....	1004	1004
High Beam Indicator .....	158	158	Turn Signal Indicator .....	158	158
Instrument Cluster Illumination .....	158	158-57	* Included in Instrument Cluster Lighting.		
License Light .....	67	67	** Not Lighted		
Map Light .....	90	90			

### FUSES

CIRCUIT	Fuse Type	Ampere Rating
Accessories .....	3 AG/AGC	20 AMP
Cigar Lighter .....	3 AG/AGC	20 AMP
Heater or Air Cond. ....	3 AG/AGC	20 AMP
Instrument Lights .....	3 AG/AGC	2 AMP Dart 3 AMP Coronet
Radio .....	3 AG/AGC	5 AMP
Tail, Stop, Done .....	3 AG/AGC	20 AMP